
www.teknikoffice.co.uk

Teknik



For **things** 'n such.

Wall Mounted Peg Board

Craft Collection | Model 5423411


NOTE: THIS INSTRUCTION BOOKLET CONTAINS <u>IMPORTANT</u> SAFETY INFORMATION.

PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Table of Contents

Assembly Tools Required

Part Identification	3
Hardware Identification	3
Assembly Steps	4-7
Français	8-9
Español	10-11
Safety	12-14
Warranty	15




Part Identification




While not all parts are labeled, some of the parts will have a label or an inked letter on the edge to help distinguish similar parts from each other. Use this part identification to help identify similar parts.

A UNIT (1)




Hardware Identification

Screws are shown actual size. You may receive extra hardware with your unit.










6 SILVER 7/16" PAN HEAD SCREW - 4








- Assemble your unit on a carpeted floor or on the empty carton to avoid scratching your unit or the floor.
- Turn the UNIT (A) onto its front edges.
- To hang your unit horizontally, fasten the BRACKETS (3) to the short edges of the UNIT (A) exactly as shown. Use four SILVER 7/16" PAN HEAD SCREWS (6).
- To hang your unit vertically, fasten the BRACKETS (3) to the long edges of the UNIT (A) exactly as shown. Use four SILVER 7/16" PAN HEAD SCREWS (6).






Fasten one of the RODS (2) to one of the TRAYS (1). Tighten two SILVER 9/16" MACHINE SCREWS (7).

*** * * * * * *** *

Repeat this for the other TRAY and ROD.


Carefully stand your unit upright either horizontally or vertically. Insert the TRAYS (1) into the hole locations of your choice.




This step shows how to hang your unit horizontally while the next step shows the unit being hung vertically.

 \diamond \diamond \diamond \diamond \diamond

- The centers of the BRACKETS used to hang your unit are spaced 25-5/8" apart. With your tape measure, measure the distance on your wall. Then, mark the locations on your wall with a pencil. The marks should be 2-1/4" down from the top of your unit.
- Next, drill the holes that are marked on the wall using a 1/4" drill bit.
- NOTE: If attaching the Peg Board to a wall made of concrete, plaster, or other material, go to your local hardware store for proper hardware.
- Using your hammer, gently tap the WALL ANCHORS (4) into the holes in your wall. Then, turn two SILVER 1-1/2" PAN HEAD SCREWS (5) into the WALL ANCHORS (4).
- NOTE: Do <u>not</u> use a power screwdriver to tighten the SCREWS.
- NOTE: Do <u>not</u> completely tighten the SCREWS. There should be approximately a 3/16" gap between the SCREW and WALL ANCHOR.
- Carefully insert the SCREWS in your wall into the large holes in the brackets on the back of your unit. Then set the unit down into place.



- The centers of the BRACKETS used to hang your unit are spaced 19-11/16" apart. With your tape measure, measure the distance on your wall. Then, mark the locations on your wall with a pencil. The marks should be 3" down from the top of your unit.
- Next, drill the holes that are marked on the wall using a 1/4" drill bit.
- NOTE: If attaching the Peg Board to a wall made of concrete, plaster, or other material, go to your local hardware store for proper hardware.
- Using your hammer, gently tap the WALL ANCHORS (4) into the holes in your wall. Then, turn two SILVER 1-1/2" PAN HEAD SCREWS (5) into the WALL ANCHORS (4).
- NOTE: Do <u>not</u> use a power screwdriver to tighten the SCREWS.
- NOTE: Do <u>not</u> completely tighten the SCREWS. There should be approximately a 3/16" gap between the SCREW and WALL ANCHOR.
- Carefully insert the SCREWS in your wall into the large holes in the brackets on the back of your unit. Then set the unit down into place.
- NOTE: Please read the back pages of the instruction booklet for important safety information.
- This completes assembly. Clean with your favorite furniture polish or a damp cloth. Wipe dry.



▲ WARNING

Please use your furniture correctly and safely. Improper use can cause safety hazards,

or damage to your furniture or household items. Carefully read the following chart.		
Look out for:	What can happen:	How to avoid the problem:
Properly mounting the shelf to the wall.	• If not properly mounted, the shelf can fall from the wall and cause injury and damage.	Carefully review and follow the mounting instructions contained in this manual.
Overloaded shelves.	Risk of injury or property damage. Overloaded furniture can break.	Never exceed the weight limits shown in the instructions.
 Improper use of furniture to support TV's. Placing TV's on furniture items not intended to support them is hazardous. 	Risk of injury or death. TV's can be very heavy. Plus the weight and location of the picture screen can make furniture tip forward.	This product is not designed to support a television.