

ASSEMBLY AND ADJUSTMENT INSTRUCTIONS
ERGO PLUS

TEKNIK OFFICE LTD
SALES & SERVICE:
Phone: + 1234 328804
Fax: + 1234 342446
Mail: service@teknikoffice.co.uk



Tension adjustment of back and seat inclination



Reclining of the back / the seat



Height adjustment of the back*



Adjustable sliding seat



Height adjustment of the seat



Lumbar adjustment

*Please note: The backrest height is adjusted using an "auto return" ratchet, which means once it is raised past the last click, it will fall back to the lowest position to start again. If you want the backrest set to the highest position, stop at the penultimate click.



Ax1



Bx1



Cx3



ERGO PLUS PREMIER



Dx1

Ex1

Fx5

ERGO PLUS ULTRA



Dx1

Ex1

Fx5

ERGO PLUS



Dx1

Ex1

Fx5