

It's **addicting**.

Barrister Home Lift Up Coffee Table

Model 5420329

NOTE: THIS INSTRUCTION BOOKLET CONTAINS <u>IMPORTANT</u> SAFETY INFORMATION.

PLEASE READ AND KEEP FOR FUTURE REFERENCE.


Table of Contents

Assembly Tools Required

Part Identification 3

Hardware Identification 4-5

Assembly Steps 6-23




Part Identification



While not all parts are labeled, some of the parts will have a label or an inked letter on the edge to help distinguish similar parts from each other. Use this part identification to help identify similar parts.

Α	UPPER RIGHT END (1)	
В	UPPER LEFT END (1)	
С	LOWER END (2)	
D	UPRIGHT (1)	
Е	TOP (1)	
F	BOTTOM (1)	
G	SHELF (1)	
Н	LONG SKIRT (2)	
I	SIDE SKIRT (2)	
J	BRACE (1)	
K	LONG MOLDING (2)	
L	TOP END MOLDING (2)	
М	END MOLDING (4)	
N	UPRIGHT MOLDING (2)	
0	PANEL (2)	
Р	PLINTH (4)	



Hardware Identification

You may receive extra hardware with your unit.









(15F) WOOD DOWEL - 2









(4G) METAL BRACKET - 4



(31G) CORNER BRACKET - 4



(37G) SUPPORT BRACKET - 2




(2M) BUMPER - 6



(13M) WASHER - 8



LIFT TABLE MECHANISM SET - 1



24M) NUT - 8



(91M) BUSHING - 2



(13P) CAM COVER - 12



Hardware Identification

F Screws are shown actual size. You may receive extra hardware with your unit.





























113S) BLACK 1-15/16" FLAT HEAD SCREW - 14




- Assemble your unit on a carpeted floor or on the empty carton to avoid scratching your unit or the floor.
- To begin assembly, push a SAUDER TWIST-LOCK® FASTENER (10F) into the large holes in the UPPER ENDS (A and B) and PANELS (O).







Do \underline{not} tighten the TWIST-LOCK $^{\!\scriptscriptstyle{(\!0\!)}}$ FASTENERS in this step.




Push twelve HIDDEN CAMS (1F) into the UPPER ENDS (A and B), LOWER ENDS (C), and UPRIGHT (D). Then, insert the metal end of a CAM DOWEL (2F) into each HIDDEN CAM.




Do not tighten the HIDDEN CAMS in this step.




Tap four MOLDING CONNECTORS (17F) into the notches in the MOLDINGS (K and L).



Fasten the UPPER ENDS (A and B) to the PANELS (O). Tighten four HIDDEN CAMS.






- **▼** With someone's help, flip the UPPER ENDS (A and B) and PANELS (O) over.
- Fasten the UPPER ENDS (A and B) and PANELS (O) to the MOLDINGS (K and L). Tighten ten TWIST-LOCK® FASTENERS.

How to use the SAUDER TWIST-LOCK® FASTENER


1. Insert the dowel end of the FASTENER into the hole of the adjoining part.

<u>NOTE</u>: The dowel end of the FASTENER must remain fully inserted in the hole of the adjoining part while locking the FASTENER.


2. Tighten the FASTENER with a Phillips screwdriver as tight as possible.




Fasten the SHELF (G) to the UPPER ENDS (A and B) and PANELS (O). Use eight BLACK 1-15/16" FLAT HEAD SCREWS (113S).




Fasten LOWER ENDS (C) to the SHELF (G). Tighten four HIDDEN CAMS.







- Insert two WOOD DOWELS (15F) into the holes in the SHELF (G).
- Place the UPRIGHT (D) over the WOOD DOWELS in the SHELF (G).



- Fasten the UPRIGHT MOLDINGS (N) to the UPRIGHT (D). Tighten four HIDDEN CAMS.
- Slide the END MOLDINGS* (M) onto the notched edges of the LOWER ENDS (C).
- **▼** *U.S. Patent No. 5,499,886







Fasten the BOTTOM (F) to the LOWER ENDS (C) and UPRIGHT (D). Use six BLACK 1-15/16" FLAT HEAD SCREWS (113S).




Don't worry. It isn't Rome. This can be built in a day.




- Fasten the CORNER BRACKETS (31G) to the BOTTOM (F). Use eight BLACK 9/16" LARGE HEAD SCREWS (1S).
- Fasten the SIDE SKIRTS (I) to the CORNER BRACKETS (31G). Use eight BLACK 9/16" LARGE HEAD SCREWS (1S).




Fasten the LONG SKIRTS (H) to the PLINTHS (P). Use eight SILVER 1-1/8" FLAT HEAD SCREWS (10S).




- Fasten four METAL BRACKETS (4G) to the BOTTOM (F). Use four BLACK 9/16" LARGE HEAD SCREWS (1S).
- Fasten the LONG SKIRTS (H) to the BRACKETS (4G and 31G). Use twelve BLACK 9/16" LARGE HEAD SCREWS (1S).
- NOTE: You may need to loosen the SCREWS in the CORNER BRACKETS (31G) to line up all of the holes. Once all of the holes are lined up, retighten the SCREWS in the CORNER BRACKETS.







- Fasten the LIFT TABLE MECHANISMS (23M) to the TOP (E). Use six BLACK 9/16" LARGE HEAD SCREWS (1S).
- NOTE: Be sure to position the LIFT TABLE MECHANISMS on the TOP exactly as shown.




- Fasten the SUPPORT BRACKETS (37G) to the LIFT TABLE MECHANISMS (23M). Use four WASHERS (13M), NUTS (24M), and BLACK 3/4" MACHINE SCREWS (92S).
- NOTE: Be sure to position SUPPORT BRACKETS exactly as shown.






- Carefully stand your unit upright.
- **▼** IMPORTANT: You will need someone's help in this step.
- NOTE: Be careful when lining up the holes in the MECHANISMS with the holes in the ENDS as to not damage any parts.
- 1st Line up the front two holes in each LIFT TABLE MECHANISM (23M) with the holes in the ENDS (A and B) and turn four BLACK 9/16" LARGE HEAD SCREWS (1S) a few turns into these holes.




- Finish fastening the TOP (E) to the UPPER ENDS (A and B). Use two BUSHINGS (91M) and two BLACK 3/4" PAN HEAD SCREWS (85S) through the exact holes shown in the LIFT TABLE MECHANISMS (23M) and into the holes in the ENDS.
- NOTE: Do <u>not</u> overtighten the SCREWS (85S).
- Push six BUMPERS (2M) into the LONG MOLDINGS (K).
- Push a CAM COVER (13P) onto each HIDDEN CAM.








- **▼** IMPORTANT: Do <u>not</u> place valuables in the storage space.
- Fasten the BRACE (J) to the SUPPORT BRACKETS (37G) on the LIFT TABLE MECHANISMS (23M). Use four WASHERS (13M), NUTS (24M), and BLACK 1-1/4" MACHINE SCREWS (93S).
- NOTE: Do not place the BRACE (J) between the LIFT TABLE MECHANISMS (23M).
- NOTE: Please read the back pages of the instruction booklet for important safety information.
- This completes assembly. Clean with your favorite furniture polish or a damp cloth. Wipe dry.





WARNINGPlease use your furniture correctly and safely. Improper use can cause safety hazards, or damage to your furniture or household items. *Carefully read the following chart.*

Look out for:	What can happen:	How to avoid the problem:
Overloaded shelves.	Risk of injury.Top-heavy furniture can tip over.Overloaded shelves can break.	 Never exceed the weight limits shown in the instructions. Work from bottom to top when loading shelves. Place the heavier items on the lower shelves.
Placing TVs on furniture items that are not designed to support a television is hazardous.	• Risk of injury or death. TVs can be very heavy. Plus the weight and location of the picture tube tends to make TVs unbalanced and prone to tipping forward.	This product is not designed to support a television.